


SHAD

SUZUKI V-STROM 650 '12-'15 KIT TOP SOVS62ST



1 261382 x1



2 261072 x2
Ø20 Ø9 x 32



3 303020 x2
Ø8



4 304173 x2
M8 x 75 Din 7380



5 260688 x2
Ø25 Ø11 x 16



6 304356 x2
M8 x 40 Din 7991



7 303045 x2
Ø8



8 302024 x2
Ø8

! WARNING!

GB

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

E

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

D

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

I

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

F

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

